



ARIANA AFGHAN AIRLINES

MPD Tally Sheet - Routine Jobs

A/C Model	Registration	MSN	Station	Word Order #	Title	Date	Page No.
B737-400	YA-PID	26085	Kabul	AFG-PID-26085-1217	MPD (C2-CHECK)		1 of 15

NO	TASK CARD NO	MPD REF.	ZONE & AREA	DESCRIPTION	TASK CODE	CHECKED BY
1.	20-020-31-01	B20-20-31-6C	203 204	INSPECT THE CONTROL CABLES FOR BROKEN WIRES AND WEAR IN THE NLG WHEEL WELL.	DI	
2.	20-020-32-01	B20-20-31-6D-1	216	INSPECT THE CONTROL CABLES FOR BROKEN WIRES AND WEAR IN LEFT MAIN LANDING GEAR WHEELWELL.	GV	
3.	20-020-32-02	B20-20-31-6D-2	217	INSPECT THE CONTROL CABLES FOR BROKEN WIRES AND WEAR IN THE RIGHT MAIN LANDING GEAR WHEELWELL	GV	
4.	20-020-34-01	B20-20-31-6F-1	306 307 308 309	NSPECT THE CONTROL CABLES FOR BROKEN WIRES AND WEAR IN LEFT WING AFT SPAR AREA	GV	
5.	20-020-34-02	B20-20-31-6F-2	406 407 408 409	INSPECT THE CONTROL CABLES FOR BROKEN WIRES AND WEAR IN THE RIGHT WING AFT SPAR AREA.	GV	
6.	20-020-35-01	B20-20-31-6G-1	309	INSPECT THE LEFT WING INBOARD TRAILING EDGE FLAP BOOM CABLES FOR BROKEN WIRES AND WEAR.	GV	
7.	20-020-35-02	B20-20-31-6G-2	407 409	INSPECT THE RIGHT WING INBOARD TRAILING EDGE FLAP BOOM CABLES FOR BROKEN WIRES AND WEAR	GV	



ARIANA AFGHAN AIRLINES

MPD Tally Sheet - Routine Jobs

A/C Model	Registration	MSN	Station	Word Order #	Title	Date	Page No.
B737-400	YA-PID	26085	Kabul	AFG-PID-26085-1217	MPD (C2-CHECK)		2 of 15

NO	TASK CARD NO	MPD REF.	ZONE & AREA	DESCRIPTION	TASK CODE	CHECKED BY
8.	21-032-11-01	B21-32-11-4A	220	FUNCTIONALLY CHECK THE AIR CONDITIONING PRESSURIZATION SYSTEM	FC	
9.	21-032-21-01	B21-32-21-5A	220	FUNCTIONALLY CHECK THE AIR CONDITIONING PRESSURIZATION SYSTEM SAFETY RELIEF VALVES.	FC	
10.	21-051-01-03	B21-51-00-5A-A1	101 212	OPERATIONALLY CHECK THE LEFT PACK COMPRESSOR DISCHARGE SWITCH	OP	
11.	21-051-01-04	B21-51-00-5A-A2	101 214	OPERATIONALLY CHECK THE RIGHT PACK COMPRESSOR DISCHARGE SWITCH	OP	
12.	21-058-05-01	B21-58-03-5B	101 102 205	FUNCTIONALLY CHECK THE ELECTRICAL/ELECTRONIC EQUIPMENT COOLING SYSTEM.	FC	
13.	21-061-01-01	B21-61-00-5A-A	101 102 107 108 205 210	OPERATIONALLY CHECK THE AFT AND FORWARD PASSENGER CABIN & FLIGHT COMPARTMENT	OP	
14.	22-011-01-01	B22-11-01-5A	101	OPERATIONALLY TEST THE AUTO ELECTRICAL POWER TRANSFER TO THE AUTOPILOT ELECTRICAL BUS.	OP	



ARIANA AFGHAN AIRLINES

MPD Tally Sheet - Routine Jobs

A/C Model	Registration	MSN	Station	Word Order #	Title	Date	Page No.
B737-400	YA-PID	26085	Kabul	AFG-PID-26085-1217	MPD (C2-CHECK)		3 of 15

NO	TASK CARD NO	MPD REF.	ZONE & AREA	DESCRIPTION	TASK CODE	CHECKED BY
15.	22-011-25-01	B22-11-25-4A	216	CHECK THE AUTOPILOT AILERON SERVO ACTUATOR LEVER ASSEMBLY SHEAR RIVETS FOR WEAR	GV	
16.	22-011-26-01	B22-11-26-4A	704	CHECK THE AUTOPILOT ELEVATOR SERVO ACTUATOR LEVER ASSEMBLY SHEAR RIVETS FOR WEAR.	GV	
17.	23-031-00-01	B23-31-00-5A	101 102 107 108 205	OPERATIONALLY CHECK THE AUDIBILITY OF PASSENGER ADDRESS SYSTEM LOUD SPEAKERS.	OP	
18.	23-061-01-01	B23-61-00-6B	301 401 706 709 710	CHECK RESISTANCE OF THE WING AND EMPENNAGE STATIC DISCHARGERS.	DI	
19.	23-071-22-01	B23-71-21-2B	218	OPERATIONALLY CHECK THE VOICE RECORDER UNDERWATER LOCATOR BEACON (ULB)	OP	
20.	24-021-00-01	B24-21-00-5A	101 102	FUNCTIONALLY CHECK THE FOLLOWING AC GENERATORS AND TRANSFER BUS CONTROL SYSTEM	FC	
21.	24-021-81-01	B24-21-81-4A	102	FUNCTIONALLY CHECK (OFF AIRPLANE) THE GENERATOR CONTROL UNITS	FC	



ARIANA AFGHAN AIRLINES

MPD Tally Sheet - Routine Jobs

A/C Model	Registration	MSN	Station	Word Order #	Title	Date	Page No.
B737-400	YA-PID	26085	Kabul	AFG-PID-26085-1217	MPD (C2-CHECK)		4 of 15

NO	TASK CARD NO	MPD REF.	ZONE & AREA	DESCRIPTION	TASK CODE	CHECKED BY
22.	24-041-21-01	B24-41-21-4A	102	FUNCTIONALLY CHECK (OFF AIRPLANE) THE BUS PROTECTION PANEL	FC	
23.	24-054-03-01	B24-54-00-5B	101 102 202	FUNCTIONALLY CHECK THE STANDBY POWER SYSTEM.	FC	
24.	26-023-01-01	B26-23-00-5E	208 218	FUNCTIONALLY CHECK THE CARGO FIRE EXTINGUISHING SYSTEM TUBING FOR EVIDENCE OF LEAKAGE OR BLOCKAGE.	FC	
25.	27-009-91-01	B27-09-91-6A-1	101 306	FUNCTIONALLY CHECK THE LEFT WING AILERON AND TAB TRAILING EDGE MOVEMENT.	FC	
26.	27-009-91-02	B27-09-91-6A-2	101 406	FUNCTIONALLY CHECK THE RIGHT WING AILERON AND TAB TRAILING EDGE MOVEMENT.	FC	
27.	27-009-92-01	B27-09-91-6B-1	101 711	FUNCTIONALLY CHECK THE LEFT ELEVATOR AND TAB TRAILING EDGE MOVEMENT.	FC	
28.	27-009-92-02	B27-09-91-6B-2	101 712	FUNCTIONALLY CHECK THE RIGHT ELEVATOR AND TAB TRAILING EDGE MOVEMENT.	FC	



ARIANA AFGHAN AIRLINES

MPD Tally Sheet - Routine Jobs

A/C Model	Registration	MSN	Station	Word Order #	Title	Date	Page No.
B737-400	YA-PID	26085	Kabul	AFG-PID-26085-1217	MPD (C2-CHECK)		5 of 15

NO	TASK CARD NO	MPD REF.	ZONE & AREA	DESCRIPTION	TASK CODE	CHECKED BY
29.	27-009-93-01	B27-09-91-6C	708	FUNCTIONALLY CHECK THE RUDDER TRAILING EDGE MOVEMENT.	FC	
30.	27-011-03-01	B27-11-00-B-1	306	VISUALLY CHECK THE FOLLOWING LEFT WING AILERON AND AILERON TRIM CONTROL SYSTEM COMPONENTS FOR CONDITION AND SECURITY OF INSTALLATION.	VC	
31.	27-011-03-02	B27-11-00-B-2	406	VISUALLY CHECK THE FOLLOWING RIGHT WING AILERON AND AILERON TRIM CONTROL SYSTEM COMPONENTS FOR CONDITION AND SECURITY OF INSTALLATION.	VC	
32.	27-021-21-01	B27-21-21-A	708	VISUALLY CHECK THE RUDDER HINGES AND BEARINGS FOR CRACKS, WEAR, DAMAGE AND SECURITY OF INSTALLATION.	VC	
33.	27-031-03-01	B27-31-00-5B	101 102	OPERATIONALLY CHECK THE ELEVATOR FEEL FORCE DIFFERENTIAL PRESSURE SWITCH.	OP	
34.	27-031-21-01	B27-31-21-A-1	711	VISUALLY CHECK THE FOLLOWING LEFT ELEVATOR COMPONENTS FOR CONDITION AND SECURITY OF INSTALLATION.	VC	
35.	27-031-21-02	B27-31-21-A-2	712	VISUALLY CHECK THE FOLLOWING RIGHT ELEVATOR COMPONENTS FOR CONDITION AND SECURITY OF INSTALLATION.	VC	



ARIANA AFGHAN AIRLINES

MPD Tally Sheet - Routine Jobs

A/C Model	Registration	MSN	Station	Word Order #	Title	Date	Page No.
B737-400	YA-PID	26085	Kabul	AFG-PID-26085-1217	MPD (C2-CHECK)		6 of 15

NO	TASK CARD NO	MPD REF.	ZONE & AREA	DESCRIPTION	TASK CODE	CHECKED BY
36.	27-051-61-01	B27-51-61-A-1	309	VISUALLY CHECK THE FOLLOWING LEFT WING INBOARD T/E FLAP COMPONENTS FOR CONDITION AND SECURITY OF INSTALLATION.	VC	
37.	27-051-61-02	B27-51-61-A-2	409	VISUALLY CHECK THE FOLLOWING RIGHT WING INBOARD T/E FLAP COMPONENTS FOR CONDITION AND SECURITY OF INSTALLATION.	VC	
38.	27-051-84-01	B27-51-84-4A	101 102 217	FUNCTIONALLY CHECK THE TRAILING EDGE FLAP SYSTEM PRIORITY VALVE.	FC	
39.	27-051-97-01	B27-51-97-4A	101 218	OPERATIONALLY CHECK THE TRAILING EDGE FLAP CABLE TENSION SWITCH.	OP	
40.	28-013-31-01	B28-13-31-7A-1	304	CLEAN THE LEFT WING AIR VENT SCOOP FLAME ARRESTOR.	RS	
41.	28-013-31-02	B28-13-31-7A-2	404	CLEAN THE RIGHT WING AIR VENT SCOOP FLAME ARRESTOR.	RS	
42.	28-013-41-01	B28-13-41-6A-1	304	PRESSURE CHECK THE LEFT WING SURGE TANK FLAME ARRESTOR PRESSURE RELIEF VALVE.	FC	



ARIANA AFGHAN AIRLINES

MPD Tally Sheet - Routine Jobs

A/C Model	Registration	MSN	Station	Word Order #	Title	Date	Page No.
B737-400	YA-PID	26085	Kabul	AFG-PID-26085-1217	MPD (C2-CHECK)		7 of 15

NO	TASK CARD NO	MPD REF.	ZONE & AREA	DESCRIPTION	TASK CODE	CHECKED BY
43.	28-013-41-02	B28-13-41-6A-2	404	PRESSURE CHECK THE RIGHT WING SURGE TANK FLAME ARRESTOR PRESSURE RELIEF VALVE.	FC	
44.	29-015-08-01	B29-15-08-4A-1	212	REPLACE THE HYDRAULIC SYSTEM "A" GROUND SERVICE DISCONNECT FILTER ELEMENT.	DS	
45.	29-015-08-02	B29-15-08-4A-2	214	REPLACE THE HYDRAULIC SYSTEM "B" GROUND SERVICE DISCONNECT FILTER ELEMENT.	DS	
46.	29-015-71-01	B29-15-71-2A-1	216	REPLACE THE HYDRAULIC SYSTEM "A" PRESSURE FILTER ELEMENTS.	DS	
47.	29-015-71-02	B29-15-71-2A-2	217	REPLACE THE HYDRAULIC SYSTEM "B" PRESSURE FILTER ELEMENTS.	DS	
48.	30-021-21-01	B30-21-21-4A-1	502	REMOVE & FUNCTIONALLY CHECK (OFF-AIRCRAFT) THE LEFT ENGINE INLET COWL ANTI-ICE OVERPRESSURE SWITCH.	FC	
49.	30-021-21-02	B30-21-21-4A-2	603	REMOVE & FUNCTIONALLY CHECK (OFF-AIRCRAFT) THE RIGHT ENGINE INLET COWL ANTI-ICE OVERPRESSURE SWITCH.	FC	



ARIANA AFGHAN AIRLINES

MPD Tally Sheet - Routine Jobs

A/C Model	Registration	MSN	Station	Word Order #	Title	Date	Page No.
B737-400	YA-PID	26085	Kabul	AFG-PID-26085-1217	MPD (C2-CHECK)		8 of 15

NO	TASK CARD NO	MPD REF.	ZONE & AREA	DESCRIPTION	TASK CODE	CHECKED BY
50.	30-021-31-01	B30-21-31-4A-1	506	REMOVE AND FUNCTIONALLY CHECK (OFF AIRCRAFT) THE LEFT ENGINE INLET COWL ANTI-ICE OVERHEAT SWITCH.	FC	
51.	30-021-31-02	B30-21-31-4A-2	606	REMOVE AND FUNCTIONALLY CHECK (OFF AIRCRAFT) THE RIGHT ENGINE INLET COWL ANTI-ICE OVERHEAT SWITCH.	FC	
52.	31-024-10-01	B31-24-09-2C	108	OPERATIONALLY CHECK THE FLIGHT DATA RECORDER UNDERWATER LOCATOR BEACON (ULB).	OP	
53.	31-026-04-01	B31-26-00-5E	101 102 203 216 217	OPERATIONALLY CHECK THE LANDING AURAL WARNING SYSTEM. (AIRCRAFT ON JACKS)	OP	
54.	32-021-02-01	B32-21-00-6B	203 204	FUNCTIONALLY CHECK THE NOSE LANDING GEAR TORSIONAL FREEPLAY.	FC	
55.	32-031-71-01	B32-31-71-4A	101 102 202 217	OPERATIONALLY CHECK THE MAIN LANDING GEAR HYDRAULIC TRANSFER VALVE.	OP	
56.	32-034-00-01	B32-34-00-5A	101 102 216 217	OPERATIONALLY CHECK THE MAIN LANDING GEAR MANUAL EXTENSION (WITH AIRCRAFT ON JACKS).	OP	



ARIANA AFGHAN AIRLINES

MPD Tally Sheet - Routine Jobs

A/C Model	Registration	MSN	Station	Word Order #	Title	Date	Page No.
B737-400	YA-PID	26085	Kabul	AFG-PID-26085-1217	MPD (C2-CHECK)		9 of 15

NO	TASK CARD NO	MPD REF.	ZONE & AREA	DESCRIPTION	TASK CODE	CHECKED BY
57.	32-035-00-01	B32-35-00-5A	101 102 203	OPERATIONALLY CHECK THE NOSE LANDING GEAR MANUAL EXTENSION (WITH AIRCRAFT ON JACKS)	OP	
58.	32-041-71-01	B32-41-71-4A	217	REMOVE THE MAIN GEAR BRAKE ACCUMULATOR PRESSURE RELIEF VALVE	FC	
59.	32-044-00-01	B32-44-00-5A	101 102 216 310 410	FUNCTIONALLY CHECK THE PARKING BRAKE SYSTEM.	FC	
60.	32-061-00-01	B32-61-00-5A	101 102 204 310 410	OPERATIONALLY CHECK THE LANDING GEAR POSITION INDICATING WARNING SYSTEM. (AIRCRAFT ON JACKS)	OP	
61.	33-031-00-01	B33-31-00-C	701	OPERATIONALLY CHECK THE AFT ACCESSORY COMPARTMENT FLOOD LIGHTS.	VC OP	
62.	33-031-01-01	B33-31-00-D	704	OPERATIONALLY CHECK THE TAIL CONE COMPARTMENT DOME LIGHT.	VC OP	
63.	33-031-01-02	B33-31-00-E	703	OPERATIONALLY CHECK THE APU COMPARTMENT DOME LIGHT.	VC OP	



ARIANA AFGHAN AIRLINES

MPD Tally Sheet - Routine Jobs

A/C Model	Registration	MSN	Station	Word Order #	Title	Date	Page No.
B737-400	YA-PID	26085	Kabul	AFG-PID-26085-1217	MPD (C2-CHECK)		10 of 15

NO	TASK CARD NO	MPD REF.	ZONE & AREA	DESCRIPTION	TASK CODE	CHECKED BY
64.	33-031-01-03	B33-31-00-F	205	OPERATIONALLY CHECK THE ELECTRONIC COMPARTMENT DOME LIGHTS.	VC OP	
65.	33-031-04-01	B33-31-00-H-1	212	OPERATIONALLY CHECK THE LEFT AIR CONDITIONING EQUIPMENT BAY FLOOD LIGHTS.	VC OP	
66.	33-031-04-02	B33-31-00-H-2	214	OPERATIONALLY CHECK THE RIGHT AIR CONDITIONING EQUIPMENT BAY FLOOD LIGHTS.	VC OP	
67.	33-051-51-01	B33-51-51-A	107 108	VISUALLY CHECK THE PASSENGER CABIN EMERGENCY LIGHTING BATTERY	VC	
68.	35-022-00-01	B35-22-00-5A	103 107 108 113 114 205	OPERATIONALLY CHECK THE PASSENGER OXYGEN SYSTEM AUTOMATIC AND MANUAL	OP	
69.	35-022-31-01	B35-22-31-A	103 107 108 113 114	VISUALLY CHECK THE PASSENGER CABIN OXYGEN MASKS.	VC	
70.	35-031-00-01	B35-31-00-A	101 102 107 108	VISUALLY CHECK PORTABLE OXYGEN BOTTLES FOR CORRECT PRESSURE (1800 PSI)	VC	



ARIANA AFGHAN AIRLINES

MPD Tally Sheet - Routine Jobs

A/C Model	Registration	MSN	Station	Word Order #	Title	Date	Page No.
B737-400	YA-PID	26085	Kabul	AFG-PID-26085-1217	MPD (C2-CHECK)		11 of 15

NO	TASK CARD NO	MPD REF.	ZONE & AREA	DESCRIPTION	TASK CODE	CHECKED BY
71.	52-021-00-01	B52-21-00-5A-1	117 117A	OPERATIONALLY CHECK THE LEFT EMERGENCY EXIT HATCH	OP	
72.	52-021-00-02	B52-21-00-5A-2	116 116A	OPERATIONALLY CHECK THE RIGHT EMERGENCY EXIT HATCH	OP	
73.	52-031-13-01	B52-31-13-6A-A	208 209	OPERATIONALLY CHECK THE FWD CARGO DOOR SNUBBER.	OP	
74.	52-031-13-02	B52-31-13-6A-B	218 219	OPERATIONALLY CHECK THE AFT CARGO DOOR SNUBBER.	OP	
75.	52-049-11-01	B52-49-11-4A	702	FUNCTIONALLY CHECK THE SECTION 48 ACCESS AND BLOWOUT DOOR	FC	
76.	52-311-01-01	P52-11-00-B-1	105	CORROSION PREVENTION: FORWARD ENTRY DOOR, INTERNAL	CP	
77.	52-311-01-02	P52-11-00-B-2	106	CORROSION PREVENTION: FORWARD GALLEY DOOR, INTERNAL	CP	



ARIANA AFGHAN AIRLINES

MPD Tally Sheet - Routine Jobs

A/C Model	Registration	MSN	Station	Word Order #	Title	Date	Page No.
B737-400	YA-PID	26085	Kabul	AFG-PID-26085-1217	MPD (C2-CHECK)		12 of 15

NO	TASK CARD NO	MPD REF.	ZONE & AREA	DESCRIPTION	TASK CODE	CHECKED BY
78.	52-313-01-01	P52-13-00-B-1	110	CORROSION PREVENTION: AFT ENTRY DOOR, INTERNAL	CP	
79.	52-313-01-02	P52-13-00-B-2	112	CORROSION PREVENTION: AFT GALLEY DOOR, INTERNAL	CP	
80.	53-001-03-01	B53-00-00-R	208	VISUALLY CHECK THE FORWARD CARGO COMPARTMENT FLOOR BEAMS AND FLOOR STRUCTURE	VC	
81.	53-001-03-02	B53-00-00-S	218	VISUALLY CHECK THE AFT CARGO COMPARTMENT FLOOR BEAMS AND FLOOR STRUCTURE	VC	
82.	53-310-01-01	P53-10-00-C-1	211	CORROSION PREVENTION: LEFT AIR CONDITIONING RAM AIR DUCT	CP	
83.	53-310-01-02	P53-10-00-C-2	213	CORROSION PREVENTION: RIGHT AIR CONDITIONING RAM AIR DUCT	CP	
84.	53-310-02-01	P53-10-00-D-1	208	CORROSION PREVENTION: FORWARD LOWER LOBE INTERIOR STRUCTURE REFERENCE: CORROSION PREVENTION MANUAL D6-82560	CP	



ARIANA AFGHAN AIRLINES

MPD Tally Sheet - Routine Jobs

A/C Model	Registration	MSN	Station	Word Order #	Title	Date	Page No.
B737-400	YA-PID	26085	Kabul	AFG-PID-26085-1217	MPD (C2-CHECK)		13 of 15

NO	TASK CARD NO	MPD REF.	ZONE & AREA	DESCRIPTION	TASK CODE	CHECKED BY
85.	53-310-02-02	P53-10-00-D-2	218	CORROSION PREVENTION: AFT LOWER LOBE INTERIOR STRUCTURE REFERENCE: CORROSION PREVENTION MANUAL D6-82560	CP	
86.	53-311-01-01	P53-11-00-B	701	CORROSION PREVENTION: AFT PRESSURE BULKHEAD, STATION 1016 AFT FACE	CP	
87.	53-351-00-01	P53-51-00-A-1	100	CORROSION PREVENTION: LEFT WING TO BODY FAIRING CAVITY STRUCTURE	CP	
88.	53-351-00-02	P53-51-00-A-2	100	CORROSION PREVENTION: RIGHT WING TO BODY FAIRING CAVITY STRUCTURE	CP	
89.	55-310-01-01	P55-10-00-B-1	709	CORROSION PREVENTION: LEFT HORIZONTAL STABILIZER STRUCTURE	CP	
90.	55-310-01-02	P55-10-00-B-2	710	CORROSION PREVENTION: RIGHT HORIZONTAL STABILIZER STRUCTURE	CP	
91.	55-310-02-01	P55-10-00-C	701	CORROSION PREVENTION: HORIZONTAL STABILIZER - ATTACHED LEFT AND RIGHT HINGE FITTINGS	CP	



ARIANA AFGHAN AIRLINES

MPD Tally Sheet - Routine Jobs

A/C Model	Registration	MSN	Station	Word Order #	Title	Date	Page No.
B737-400	YA-PID	26085	Kabul	AFG-PID-26085-1217	MPD (C2-CHECK)		14 of 15

NO	TASK CARD NO	MPD REF.	ZONE & AREA	DESCRIPTION	TASK CODE	CHECKED BY
92.	55-320-00-01	P55-20-00-A-1	711	CORROSION PREVENTION: LEFT ELEVATOR BALANCE PANEL SURFACES	CP	
93.	55-320-00-02	P55-20-00-A-2	712	CORROSION PREVENTION: RIGHT ELEVATOR BALANCE PANEL SURFACES	CP	
94.	55-330-00-01	P55-30-00-A	706	CORROSION PREVENTION: VERTICAL STABILIZER SKIN, REAR SPAR, AND IN THE VICINITY OF THE REAR ATTACH FITTINGS.	CP	
95.	55-350-00-01	P55-50-00-A	706	CORROSION PREVENTION: VERTICAL STABILIZER-TO-BODY ATTACH FITTINGS	CP	
96.	73-034-00-01	C73-34-00-5A-1	101 506	OPERATIONALLY CHECK THE LEFT ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH.	OP	
97.	73-034-00-02	C73-34-00-5A-2	101 606	OPERATIONALLY CHECK THE RIGHT ENGINE FUEL FILTER DIFFERENTIAL PRESSURE SWITCH.	OP	
98.	79-011-01-01	C79-11-01-6A-1	506	VISUALLY CHECK THE LEFT ENGINE OIL TANK FOR CONDITION AND SECURITY OF INSTALLATION	VC	



ARIANA AFGHAN AIRLINES

MPD Tally Sheet - Routine Jobs

A/C Model	Registration	MSN	Station	Word Order #	Title	Date	Page No.
B737-400	YA-PID	26085	Kabul	AFG-PID-26085-1217	MPD (C2-CHECK)		15 of 15

NO	TASK CARD NO	MPD REF.	ZONE & AREA	DESCRIPTION	TASK CODE	CHECKED BY
99.	79-011-01-02	C79-11-01-6A-2	606	VISUALLY CHECK THE RIGHT ENGINE OIL TANK FOR CONDITION AND SECURITY OF INSTALLATION.	VC	
100.	79-035-00-01	C79-35-00-5A-1	506	FUNCTIONAL CHECK THE LEFT ENGINE OIL FILTER BYPASS WARNING SWITCH.	FC	
101.	79-035-00-02	C79-35-00-5A-2	606	FUNCTIONAL CHECK THE RIGHT ENGINE OIL FILTER BYPASS WARNING SWITCH.	FC	